


RAN₁₀

OPERATING INSTRUCTIONS

Renew
Reaching The Remote




CHARGING THE BATTERY...

...using the sun



Face solar panel towards sun 1 full day

...using AC power



Plug into wall overnight



RUNNING THE PLAYER...

...from the battery



...from AC power



PLAYING A MOVIE

Return button selects the raised icon



RAN₁₀ PARTS LIST

- 1 10" RAN Screen
- 2 Carrying Case
- 3 Solar Panel
- 4 Rechargeable Battery
- 5 Remote Control
- 6 AC Power Cord
- 7 Battery to RAN Cord



ON-UNIT CONTROLS...

...in Menu

Up

Down

Left

Right

Select

Menu



...in Movie

Volume Up



Volume Down



Skip Back



Skip Forward




Play / Pause



On-Screen Display

Menu



EXTERNAL AMP/SPEAKER

